



09/2019

- Please read the Use, Care and Safety Advice thoroughly.
- Judge cookware has a 25 year Stainless Steel Guarantee to be free from defects in material and workmanship under normal household use.
- We promise to the original purchaser that any defective part or item will be replaced, (or we will supply a product of equal value if the product is out of production).
- The Guarantee does not cover damage by accident, misuse or commercial use. In addition, discoloration, scratching, staining and damage from overheating is not covered by the Guarantee.
- This Guarantee is in addition to your statutory rights.

www.horwood.co.uk

JUDGE Horwood Avonmouth Way
Bristol BS11 9HX Great Britain
Tel: 0117 940 0000
customerservice@horwood.co.uk



JUDGE Vista

CHIP PAN
CARE, USE AND SAFETY ADVICE - 25 YEAR GUARANTEE

BEFORE USE

- Remove labels, wash in hot soapy water, rinse and dry.

HOB SUITABILITY

- Judge Vista cookware is suitable for use on all hob types, including induction.
- To minimise scratching on glass top hobs always lift pans, do not drag.

INDUCTION HOB USE

- These highly efficient hobs transfer heat to the cookware immediately by magnetic fields. Extremely high temperatures can be reached in seconds.
- Always heat pans gradually, by initially using a lower power setting, then gradually raise to the desired setting.
- Never heat an empty pan, as this can potentially cause damage, especially to non-stick coatings.

IMPORTANT SAFETY ADVICE

- **The glass lid should never be used while frying.**

Never fill the chip pan more than a third full of oil:

- **JJ83 (20cm)**
Max fill level 800ml
- **JJ84 (22cm)**
Max fill level 1.5L

- **Never leave your chip pan unattended when in use.**

IN THE EVENT OF A FIRE

- **Call the Fire Service on 999 immediately.**
- **Turn off the heat (only if its safe to do so).**
- **Never move the pan.**
- **Never use water on chip pan fires, as this will cause a fireball.**
- **Have a clear escape route.**
- **Do not take risks.**

COOKING

- Always match the size of the pan base to the size of the heating area.
- Use a moderate heat and do not allow the pan to boil dry.
- If a pan has boiled dry, do not remove from the hob until it has fully cooled.
- Do not pour cold water into a hot pan, as this may cause warping.
- Excessive heat will spoil the appearance of the pan by causing tinting on the surface
- Do not heat an empty pan.
- Never allow a gas flame to extend up the sides of a pan, as it can cause overheating and damage handles.
- Do not add salt to a pan of cold water - this can cause white

marks or pitting on stainless steel surfaces.

- Do not store food in the pans
- The range is not suitable for microwave oven use.
- Always use oven gloves or similar when moving hot pans around the hob or oven.
- **BE AWARE THAT HOT WATER AND STEAM CAN CAUSE INJURY UNLESS CARE IS TAKEN.**
- Ensure that handles are not positioned over other heating elements, and that they do not overhang the edge of the hob.
- Never leave a pan unattended on a hob.
- Verify that knobs and handles remain secure. Due to the extremes in temperature, over time, the handle can sometimes work loose. Simply tighten the Philips head screw on the underside of the handle.

CLEANING

- Soak the pans for a few minutes before washing.
- Remove food deposits with a nylon pan scourer or brush.
- Wash pan in hot soapy water, rinse and dry thoroughly.
- The pans are dishwasher safe. Black Phenolic fittings may become discoloured after

repeated dishwasher use.

- You can recover the original brightness of stainless steel and remove stubborn marks, such as white marks caused by water which is 'hard' or high in mineral content, by occasional use of a product such as - Stellar Stainless Steel Cleaner, which is specially recommended for Judge cookware - available from your Judge stockist or customer service.

HANDLES & KNOBS

- Black phenolic handles and knobs are oven safe to 150°C (Gas Mark 3, 300°F).
- Spares are available from customer service, see contact details on reverse.

GLASS LIDS

- If your cookware has glass lids you should be aware that although these have been designed to be as safe as possible, glass can break under certain circumstances.
- Avoid placing glass lids directly on a hot-plate, as this greatly reduces breakage resistance.
- If you should be unfortunate enough to break a glass lid please contact Customer service, see contact details on reverse.