


 **JUDGE**
INDUCTION

HOB TOP KETTLE


1.5 Litre, 2.6 Pint

**USE, CARE AND
SAFETY ADVICE**



This Judge induction-ready Hob Top Kettle will give many years' service: please read these instructions before use.

**HOT WATER AND STEAM CAN BE DANGEROUS, AND
FOR YOUR OWN SAFETY WE ASK YOU TO FOLLOW
THESE GUIDELINES**



**WHEN FILLING, NEVER ALLOW WATER
TO COVER THE TOP HOLE.**

Remove any labels and wash the kettle in hot water before first use. Refill with fresh water, boil and discard.

The base of the kettle must always be covered by water when heating - **never heat an empty kettle.**

Always try to **match the hob hotplate size to the kettle base size** (unless using an Aga or Rayburn).

Do not overfill - SEE DIAGRAM. The water level must never be allowed to cover the TOP hole of the four 'spout' holes inside the kettle.

Ensure the lid is firmly in position, and the lid steam vent is pointing toward the spout.

Do not leave the kettle simmering for long periods - the base and enamel coating may be damaged if it boils dry.

Avoid banging the kettle on the hob - repeated knocks may damage the enamel.

Do not leave water in the kettle when it is not in use, as this can lead to build-up of limescale which reduces efficiency.

FOR AGA AND RAYBURN USE:

Do not use the Simmering Plate - always use the Fast Plate.

If the stove Plate Cover has been left open, closing it to restore heat build-up will speed the boiling time.

THERE IS A COMPLETE RANGE OF JUDGE
INDUCTION ENAMEL-COATED STEEL COOKWARE
AND OVENWARE AVAILABLE FROM
YOUR JUDGE STOCKIST.



Avonmouth Way Bristol
Great Britain BS11 9HX

sales@horwood.co.uk

www.horwood.co.uk